



Part #2092 Front Bar 1998-2003

8-29-2005

- Step 1. Jack up driver's side of truck and remove wheel. ALWAYS USE JACK STANDS!!**
- Step 2. Disassemble factory bar and remove from driver's side.**
- Step 3. Install new bar from driver's side.**
- Step 4. Install mid-section adaptor plates.**
- Step 5. Install mid-section brackets and bushings. Be sure and lube the inside of the bushings with a good synthetic lubricant to prevent squeaking.**
- Step 6. Install end-links. DO NOT OVER TIGHTEN! You should still be able to turn the center spacer tube with your hand when proper tightness is achieved.**

NOTE: It may be necessary to slightly bend the brake line so they don't interfere with the end-links.

Familiarize yourself with the new handling characteristics of your truck. As we cannot supervise installation we cannot be held responsible for more than the cost of a replacement bar.

Hardware
2 RH 010 End-Links
2 UB 614W Bushings
2 RH 072W Brackets
2 RH 704 Adaptor Plates