



PART # 2303

IMPORTANT: READ BEFORE INSTALLATION!!

- STEP# 1** LOCATE THE TAPPED HOLES IN THE BOTTOM OF THE FRAME WHICH ARE ROUGHLY ONE FOOT BEHIND THE REAR AXLE. THIS IS WHERE THE BAR INSTALLS.
- STEP# 2** PLACE THE BAR OVER THE TAIL PIPE WITH THE ARMS POINTING FORWARD.
- STEP# 3** INSTALL THE MIDSECTION BUSHINGS AND BRACKETS TO THE BAR. BE SURE TO GREASE THE INSIDES OF THE BUSHINGS.
- STEP# 4** USING THE THREE SUPPLIED BOLTS AND WASHERS, ALONG WITH THE FUEL PUMP MOUNTING BOLT, ATTACH THE BAR TO THE FRAME.
- STEP # 5** REMOVE THE LOWEST NUT ATTACHING THE STRUT TO THE SUSPENSION AND INSTALL THE ANGLE BRACKET AS SHOWN IN THE ILLUSTRATION.
- STEP # 6** INSTALL THE END LINKS AND TIGHTEN UNTILL SNUG. BE SURE NOT TO OVERTIGHTEN THEM.
- STEP# 7** AFTER THE INSTALLATION IS COMPLETE; BOUNCE THE CAR TO CHECK THE CLEARANCE OF ALL PARTS THROUGH OUT THE SUSPENSION TRAVEL DISTANCE.
- STEP# 8** ROAD TEST YOUR CAR TO FAMILIARIZE YOURSELF WITH ITS NEW HANDLING. AS WE CANNOT SUPERVISE YOUR INSTALLATION OR YOUR DRIVING, WE CANNOT BE HELD RESPONSIBLE FOR MORE THAN THE COST OF THE KIT. FOR BEST BALANCE AND CONTROL, THIS BAR SHOULD BE USED IN CONJUNCTION WITH OUR REAR/FRONT KIT.

HARDWARE LIST:

- | | |
|-------------------|------------------|
| 2 - 612B Bushings | 2 - 46C Brackets |
| 2 - 016 End-Links | 3 - RH 211 Bolts |
| 3 - 105 Washers | 2 - RH 023 Bolts |
| 4 - 110 washers | |

Direction # 2303

Neon 00-05

← FRONT

