



2330 TJ All-Terrain Sway bar Installation Instructions

Step 1:

Remove your current front anti-sway bar along with its mounting hardware.

Step 2:

Depending on the style of your front bumper, it may need to be removed in order to install the ADDCO bar. Locate the tubular cross member just behind the front bumper and install one of the supplied white bushings into the drivers' side. These are a very tight fit!

Step 3:

Remove the passenger side arm of the ADDCO bar and push it through the bushing mentioned in step 2 (also a very tight fit). Once the drivers side arm is flush with the bushing install the remaining bushing to the passenger side of the cross member along with the locking collar (this will locate the bar laterally).

Step 4:

Install the passenger side arm and secure it with the supplied bolt and lock washer. Install end links.

NOTE: Due to extreme variances in vehicle height we are unable to supply endlinks with this kit. However custom length end links may be obtained by calling ADDCO at 800-621-8916.

Step 5:

Have someone bounce the front of your vehicle so you can check that all parts have proper clearance throughout the suspension travel. Road test your vehicle, to familiarize yourself with its new handling characteristics. As we cannot supervise the installation, or your driving, ADDCO cannot be held responsible for more than the cost of the kit.

Hardware

1 - RH197 Bolt

1 - RH115 Lock washer

1 - RH151 Split Collar

2 - RH809 Bushings