



**DIRECTIONS 2347**

**TOYOTA CRESSIDA/IRS –REAR**

**THIS HEAVY DUTY ANTI-SWAY BAR IS DESIGNED TO REPLACE THE EXISTING LIGHT DUTY BAR ON THE CAR.**

**NOTE: THE BRACKET THAT HOLDS THE BAR AND BUSHING IS A TWO PIECE PART THAT ENABLES YOU TO ENGAGE THE HOOK HALF IN THE SLOT AND START THE BOLT IN THE HOLE BEFORE PUSHING THE BAR AND BUSHING INTO PLACE. THEN CINCH TOGETHER THE HALVES WITH THE SUPPLIED 5/16" BOLT AND LOCK-NUT.**

**As we cannot supervise your installation, or your driving, we cannot be held responsible for more than the cost of the kit.**

**NOTE: For best balance and control, this kit should be used in conjunction with our front bar kit.**

**HARDWARE:**

- 2 RH 042B Brackets**
- 2 RH 218 Bolts**
- 2 RH 307 Lock-Nuts**
- 2 RH 015 End-Links**
- 2 UB 611 Bushings**